# Follow Spot Light



Use Manual

PROFESSIONAL LIGHTING EQUIPMENT

## buy on www.cablematic.com

#### Instruction

Thank you for trusting and choosing our product. Wish you will satisfy for our products. In order to use this Bubble Machine in security, please read the Use Manual seriously.

#### Productbriefintroduction

This Light uses the advance technology, high effect optics system so that let this light has the steady capability and high brightness. The cast shell use the Aluminum alloy and let it has the good give out the heat and good shape.

## **OperationManual**

Open the packing, please check the light in good status, and then put in the fit location and set up the stand well. Connect the power and turn on the light, the system will be time-lapse in 10sec and into the checking status, check itself about 30sec later, the buttons can be controlled.

When in using press the "RISING HOOD" turn on the light, and then press the "BIG LIGHT CIRCLE" or "SMALL LIGHT CIRCLE" adjust the zoom, choose color ("WHITE" "BLUE" "YELLOW" "GREEN" "RED"). If want the special effects, please press the "FLASH" in strobe flash, press again it stops flash.

When in using, if has some other statuses, you can press the "RESET".

# TechnologyParameter

Voltage: AC220V~240V/.50HZ-60HZ

Power: **1350W** 

Light-Source: HMI-1200W

Resist the voltage: **1.5KV** Insulated resistance: **72M\Omega** 

Color: 5Colors + White beam

Zoom: Adjusting

Flash: 1-5Hz

#### buy on www.cablematic.com

## Safetystatement

!!!Don't open the cover for yourself, pay attention to get an electric shock.

- a) When move the Light, please ensure the power cutting.
- b) Don't use the falling short of lamps.
- c) The light in using it will be getting high heat, please keep the tinder at least far away 0.5 meters of the light and please don't use hand to touch the light when it is in using.
  - d) Please keep the light beam shine at least 2meters away from the objects.
- e) Please don't use eyes to see the beam directly otherwise it is possible to hurt the eyes.
  - f) The better is use the light not more than 6Houurs once.
  - g) When turn off the light, the better is 20mins later just turn on again.

# OperationMap

RESET BIGLEZGHTCIRCLE

STROBE SMALLLIGHTCIRCLE

ON/OFF WHITE RED YELLOW BLUE GREEN